

90mm Shower Tray Waste Installation and Assembly Instructions

1. Remove upper assembly and seals from the bottom trap.
2. Re-assemble on to the Shower Tray as shown in diagram below. NB: The upper seal fitting is optional.
3. To clean the trap, remove the dome then twist and remove the inner section (not shown). Wipe clean, re-assemble and fit.

NB: A suitable quality silicone sealant should be used on all surfaces against the Shower Tray.

